ECONOMIC COMMISSION FOR EUROPE

INLAND TRANSPORT COMMITTEE

Working Party on the Construction of Vehicles

Working Party on General Safety Provisions (GRSG)
(Eighty-first session, 8-12 October, 2001,
agenda item 11.1.)

### PROPOSAL FOR A GLOBAL TECHNICAL REGULATION (GTR) CONCERNING UNIFORM PROVISIONS FOR LOCATION AND IDENTIFICATION OF MOTOR VEHICLE HAND CONTROLS, TELL-TALES AND INDICATORS

## Transmitted by the Expert from Canada

<u>Note</u>: The text reproduced below was prepared by the expert from Canada. The technical content of this document is essentially identical to the draft of a new Regulation, proposed to be annexed to the 1958 Agreement - informal document No. 10 presented at the eighty-first session of GRSG.

GE.01-

 $<sup>\</sup>underline{\text{Note}}$ : This document is distributed to the Experts on General Safety Provisions only.

# Global Technical Regulation No. XXX

# UNIFORM PROVISIONS FOR LOCATION AND IDENTIFICATION OF MOTOR VEHICLE HAND CONTROLS, TELL-TALES AND INDICATORS

#### 1. SCOPE

This Regulation applies to power-driven vehicles intended for use on the road, with or without bodywork and a maximum design speed exceeding 25 km/h. It does not apply to motorcycles, vehicles that run on rails and to agricultural and forestry tractors and machinery. This Regulation specifies requirements for the location, identification, colour, and illumination of motor vehicle controls, tell-tales and indicators. It is designed to ensure the accessibility and visibility of vehicle controls, tell-tales, and indicators and to facilitate their selection under daylight and night-time conditions, in order to reduce the safety hazards caused by the diversion of the driver's attention from the driving task and by mistakes in selecting controls.

2. DEFINITIONS

For the purpose of this regulation

- 2.1. "Control" means that hand-operated part of a device that enables the driver to bring about a change in the state or functioning of a vehicle or vehicle's subsystem.
- 2.2. "Device" means an element or an assembly of elements used to perform one or more functions.
- 2.3. "Indicator" means a device that shows the magnitude of the physical characteristics that the instrument is designed to sense.
- 2.4. "Common space" means an area on which two or more information functions (e.g. symbols) may be displayed but not simultaneously.
- 2.5. "Tell-tale" means an optical signal that, when alight, indicates the actuation of a device, a correct or defective functioning or condition, or a failure to function.
- 2.6. "Adjacent" means that no control, tell-tale, indicator, or other potential source of distraction appears between the identifying symbol and the tell-tale, indicator, or control which that symbol identifies.
- 3. [reserved]
- 4. [ reserved ]
- 5. SPECIFICATIONS

A vehicle fitted with a control, a tell-tale or an indicator, listed in table 1 or ISO 2575:2000 standard, shall meet the prescribed requirements of this regulation for the location, identification, colour, and illumination of such control, tell-tale or indicator.

- 5.1 LOCATION
- 5.1.1. The controls to be used by a driver while driving the vehicle shall be located so that they are operable by this driver under the conditions of paragraph 5.6.2.
- 5.1.2. The tell-tales and indicators listed in table 1, shall be located so that they are visible and recognisable to a driver during night and day under the conditions of paragraphs 5.6.1. and 5.6.2. Tell-tales and indicators need not be visible or recognisable when not activated.
- 5.1.3. The identifications of tell-tales, indicators and controls shall be placed on or adjacent to the tell-tales, indicators and controls that they identify. In the case of a multifunction control, the identification need not be immediately adjacent.
- 5.1.4. Notwithstanding paragraphs 5.1.1., 5.1.2. and 5.1.3. the tell-tale for "passenger air bag off", if fitted, must be located within the interior of the vehicle and forward of and above the design H-point of both the driver's and the right front passenger's seat in their forwardmost seating positions. The tell-tale which alerts front seat occupants that the passenger side air bag is switched off must be visible to the driver and right front passenger under all driving conditions and shall not be located on or adjacent to a surface that can be used for temporary or permanent storage where use of the storage space could obscure the telltale from either the driver's or right front passenger's view.
- 5.2. IDENTIFICATION
- 5.2.1. Where fitted, the controls, tell-tales and indicators, listed in column 1 of table 1, shall be identified by symbols designated for them in column 2 of table 1. This requirement does not apply to the horn (an audible warning signal) control, when it is activated by a narrow ring-type control or by a lanyard. Control, tell-tale or indicator not listed in table 1 shall be identified by symbol designated for the purpose in standard ISO 2575:2000 where one exists.
- 5.2.2. To identify a control, a tell-tale or an indicator not included in table 1 or ISO 2575:2000, the manufacturer may use a symbol of its own conception. Such symbol may include internationally recognised alphabetic or numeric indications. All symbols used shall follow the design principles laid down in paragraph 4. of ISO 2575:2000.
- 5.2.3. If necessary for clarity, supplementary symbols may be used in conjunction with any symbol specified in table 1 or ISO 2575:2000.
- 5.2.4. Each additional or supplementary symbol used by the manufacturer must not cause confusion with any symbol specified in this regulation.
- 5.2.5. Where a control, an indicator or a tell-tale for the same function are combined, one symbol may be used to identify such combination.
- 5.2.6. Except as provided in paragraph 5.2.9., all identifications of telltales, indicators and controls listed in table 1 or ISO 2575:2000 must appear to the driver perceptually upright. In case of rotating control, this paragraph applies to it when such control is in its "off" position.

- 5.2.7. The identification of the following need not appear to the driver perceptually upright:
- 5.2.7.1. a horn control,
- 5.2.7.2. any control, tell-tale or indicator located on the steering wheel, when the steering wheel is positioned for the motor vehicle to travel in other than a straight forward direction, and
- 5.2.7.3. any rotating control that does not have an off position.
- 5.2.8. Each control for the automatic vehicle speed system (cruise control) and each control for heating and air conditioning system(s) shall have identification provided for each function of each such system.
- 5.2.9. When fitted each control that regulates a system function over a continuous range shall have identification provided for the limits of the adjustment range of any such function. If colour coding is used to identify the limits of the adjustment range of a temperature function, the hot limit shall be identified by the colour red and the cold limit by the colour blue. If the status or limit of a function is shown by an indicator separated from and not adjacent to the control for that function, both the control and the indicator must be independently identified in compliance with paragraph 5.1.3.

#### 5.3. ILLUMINATION

- 5.3.1. The identifications of controls for which the word "Yes" is indicated in column 4 of table 1 shall be capable of being illuminated whenever the headlamps are activated. This does not apply to controls located on the floor, floor console, steering wheel, or steering column, or in the area of windscreen header, or to controls for a heating and air-conditioning system if the system does not direct air directly upon the windscreen.
- 5.3.2. The indicators and their identifications for which the word "Yes" is indicated in column 4 of table 1 shall be illuminated whenever the device which starts and/or stops the engine is in a position which makes it possible for the engine to operate and the headlamps are activated.
- 5.3.3. The indicators, their identifications and the identifications of controls need not be illuminated when the headlamps are being flashed or operated as daytime running lamps.
- 5.3.4. At the manufacturer's discretion any control, indicator or their identifications may be capable of being illuminated at any time.
- 5.3.5. A tell-tale shall not emit light except when identifying the malfunction or vehicle condition for whose indication it is designed or during a bulb check upon propulsion system activation.

- 5.3.6. BRIGHTNESS OF ILLUMINATION OF CONTROLS AND INDICATORS
- 5.3.6.1. Means shall be provided for making the indicators, identifications of indicators and identifications of controls that are listed in table 1, visible and recognisable to the driver under all driving conditions.
- 5.3.6.2. The means for providing the required visibility
- 5.3.6.2.1. shall be adjustable to provide at least two levels of brightness, at the lower of which the identification of controls, indicators and the identification of indicators are barely discernible to the driver who has adapted to dark ambient roadway condition; and
- 5.3.6.2.2. may be operable manually or automatically.]
- 5.3.7. BRIGHTNESS OF TELL-TALE ILLUMINATION
- 5.3.7.1. Means shall be provided for making tell-tales and their identification visible and recognisable to the driver under all driving conditions.
- 5.4. COLOUR
- 5.4.1. Light of each tell-tale listed in table 1 shall be of the colour shown in column 5 of this table.
- 5.4.2. Indicators and tell-tales and identifications of indicators and controls not listed in table 1 may be of any colour chosen by the manufacturer, however, such colour must not interfere with or mask the identification of any tell-tale, control or indicator specified in table 1. The colour to be selected shall follow the guidelines specified in paragraph 5 of ISO standard 2575:2000.
- 5.4.3. Each symbol used for identification of tell-tale, control or indicator shall stand out clearly against the background.
- 5.4.4. The dark part of any symbol may be replaced by its outline.
- 5.5. COMMON SPACE FOR DISPLAYING MULTIPLE INFORMATION
- 5.5.1. A common space may be used to show information from any source, subject to the following requirements:
- 5.5.1.1. The tell-tales and indicators in the common space shall provide relevant information at the initiation of any underlying condition.
- 5.5.1.2. When the underlying condition exists for actuation of two or more tell-tales, the information shall be either
  - repeated automatically in sequence, or

- indicated by visible means and capable of being selected for viewing by the driver under the conditions of paragraph 5.6.2.

- 5.5.1.3. The tell-tales for the brake system malfunction, headlamp driving beam, direction indicator and seat belt shall not be shown in the same common space.
- 5.5.1.4. If tell-tale for the brake system malfunction, headlamp driving beam, direction indicator or seat belt is displayed in a common space it

must displace any other symbol in such common space if the underlying condition exists for its activation.

- 5.5.1.5. With the exception of tell-tales for the brake system malfunction, headlamp driving beam, direction indicator or seat belt the information may be cancellable automatically or by the driver.
- 5.5.1.6. The colour requirements regarding tell tales for engine oil pressure, seat belt and parking brake do not apply when those tell tales appear in a common space. Unless prescribed in a specific Regulation, the colour requirements regarding tell-tales do not apply when tell-tales appear in a common space.
- 5.6. CONDITIONS
- 5.6.1. The driver has adapted to the ambient light conditions.
- 5.6.2. The driver is restrained by the installed crash protection system, adjusted in accordance with the manufacturer's instructions, and is free to move within constraints of that system.
- 6. [Reserved]
- 7. [Reserved]
- 8. [Reserved]
- 9. [Reserved]
- 10. [Reserved]

Column 2 Column 5 Column 1 Column 3 Column 4 No. ITEM SYMBOL 2/ FUNCTION ILLUMINATION COLOUR Master lighting switch Control No 1. Tell-tale may not act as Tell-tale 12/ Yes 7/ Green -<u>Ď</u>the tell-tale for the 1/ position (side) lamps. Headlamp high beams No 2. Control \_ Tell-tale Yes 7/ Blue Direction indicator 3. Control No 1/,3/ Tell-tale Yes 7/ Green 4. Hazard warning signal Control Yes Tell-tale 4/ Yes <u>7</u>/ Red 1/ 5. Front fog lamps Control No Tell-tale Yes 7/ Green 1/ Rear fog lamp Control No 6. Tell-tale Yes 7/ Yellow 7. Fuel level Tell-tale Yes 7/ Yellow Ð Yes Indicator B 8. Engine oil pressure Tell-tale Yes 7/ Red ٩٣ L <u>\_\_\_5</u>/ Indicator Yes Engine coolant Tell-tale Yes 7/ Red 9. **∠** <u>5</u>/ temperature Indicator Yes 10. Electrical charging Tell-tale Yes 7/ Red - + Condition Indicator Yes Windscreen wiping system 11. Control Yes (continuous) 12. Power window lock Control

Table 1. Symbols, their illumination and colours.

No.	Column 1	Column 2	Column 3	Column 4	Column 5
	ITEM	SYMBOL	FUNCTION	ILLUMINATION	COLOUR
13.	Windscreen washing system		Control	Yes	
14.	Windscreen washing and wiping system		Control	Yes	
15.	Windscreen defrosting and defogging system	<b>W</b>	Control	Yes	
			Tell-tale	Yes <u>7</u> /	Yellow
16.	Rear window defrosting and defogging system	<b>[;;;;;;;;;;;;;</b>	Control	Yes	
			Tell-tale	Yes <u>7</u> /	Yellow
17.	Position, side marker, and/or end-outline marker lamps		Control	No	
			Tell-tale 12/ /OICA/	Yes <u>6</u> / <u>7</u> /	Green
18.	Seat belt	🐇 or 🐇	Tell-tale	Yes <u>7</u> /	Red
19.	Airbag malfunction		Tell-tale	Yes <u>7</u> /	Yellow
20.	Side airbag malfunction		Tell-tale	Yes <u>7</u> /	Yellow
21.	Passenger Air bag off	["ISO K.05"] 8/	Tell-tale	Yes <u>7</u> /	Yellow
22.	Brake system malfunction	<u>8</u> /	Tell-tale	Yes <u>7</u> /	<del>Red</del> see brake Reg.
23.	Antilock brake system malfunction		Tell-tale	Yes <u>7</u> /	Yellow
24.	Speedometer	km/h and <b>/or</b> MPH	Indicator	Yes	
25.	Parking brake applied	(P) <u>9</u> /	Tell-tale	Yes <u>7</u> /	Red
26.	Horn	þ	Control	No	

		I		1	T
No.	Column 1	Column 2	Column 3	Column 4	Column 5
	ITEM	SYMBOL	FUNCTION	ILLUMINATION	COLOUR
27.	Engine on-board diagnostics or engine malfunction		Tell-tale	Yes <u>7</u> /	Yellow
28.	Air Conditioning System	Jor A/C	Control	Yes	
29.	Automatic (park) transmission (reverse) control (neutral) position (drive)	P R N D <u>10</u> /	Indicator	Yes	
30.	Engine Stop		Control	Yes	
31.	Brake lining wear-out condition		Tell-tale	Yes <u>7</u> /	Yellow
32.	Heating system	<u>555</u>	Control	Yes	
33.	Heating and/or air conditioning fan	$\Re_{\underline{1}}$			
34.	Instrument panel illumination	["ISO ?.??"]	Control	No	
35.	Headlamp levelling		Control	No	
36.	Odometer	<pre>km, if kilometres are shown or miles, if miles are shown</pre>			
37.	Automatic vehicle speed control (cruise control)	["ISO ?.??"]			

 $\frac{1}{2}/$  Framed areas of the symbol may be solid.  $\frac{2}{2}/$  The symbols included in this Regulation are substantially identical to symbols described in ISO 2575:2000. Proportional dimensional characteristics specified in ISO 2575:2000 shall be maintained.

 $\underline{3}$ / The pair of arrows is a single symbol. When the controls or tell-tales for left and right turn operate independently, however, the two arrows may be considered separate symbols and be spaced accordingly.

4/ Not required when arrows of turn signal tell-tales that otherwise operate independently flash simultaneously as hazard warning tell-tale.

5/ Combination of the engine oil pressure symbol and the engine coolant temperature symbol in a single tell-tale is permitted.

6/ Separate identification not required if function is combined with master lighting switch.

## 7/ See paragraph 5.3.5.

8/ Contracting Parties which, at the date of coming into force of this Regulation, allowed or required the use of text for this function may, until [sixty months] after the date of coming into force of this Regulation, continue to allow or require the text in addition to the prescribed symbols for vehicles to be

registered in their country. 9/ If a single tell-tale is used to indicate more than one brake system condition, the brake system malfunction symbol must be used. 10/ Letter "D" may be replaced or supplemented by other alphanumeric character(s) or symbol(s) chosen by the manufacturer to indicate additional selection modes. The indicators may be displayed top to bottom or left to right. 11/ Use when engine control is separate from the key locking system. 12/ Not required if instrument panel lights are lit automatically on activation of the master lighting switch.