



Flex-GTR: Proposal for Tibia Bending Moment Injury Threshold

**8th Meeting of the GRSP Flex PLI Technical Evaluation Group
Cologne, May 19th, 2009**

Oliver Zander

Bundesanstalt für Straßenwesen

Bundesanstalt für Straßenwesen

(Federal Highway Research Institute)

Anthropometric Data

PMHS Data

Injury Risk Curve

Calculation of Maximum Tibia Bending Moment

Annotations

References

Anthropometric Data

PMHS Data

Injury Risk Curve

Calculation of Maximum Tibia Bending Moment

Annotations


References

Anthropometric Data

- Values for tibial plateau height have been taken from DIN 33402-2
- Vertical distance from base to tibial plateau
- Statistically representative data (1999-2002) obtained from anthropometrical measurements of german inhabitants
- Value for 50th percentile Male aged 18-65 is in line with reference tibial plateau height of Kerrigan et al. (2004) → 460,7 mm
- Within this study, the values for 50th percentile Male aged 41-60 and 61-65 (according to PMHS data used) taken into account

DIN 33402-2:2005-12

Tabelle 8 — Tibialhöhe



Altersgruppen	Tibialhöhe mm					
	Männer			Frauen		
	Perzentil					
Jahre	5	50	95	5	50	95
18-65	430	460	480	400	425	450
18-25	440	465	500	405	430	460
26-40	435	460	485	400	425	450
41-60	425	455	475	395	420	445
61-65	420	450	470	395	420	435

Source: DIN 33402-2 (2005)

Anthropometric Data

PMHS Data

Injury Risk Curve

Calculation of Maximum Tibia Bending Moment

Annotations

References

Test	Source	Gender	Age	Stature (cm)	Body Mass (kg)	Impact Speed (m/s)	Loading Direction	Peak BM at Midspan (CFC 60) [Nm]	Peak BM at Midspan M_{Max} [Nm]	Anatomical Measurement (Heel to Tibial Plateau) L [mm]	Standardized tibia height (DIN 33402-2) L_{ref} [mm]	Scaled Fracture Moment M_{scaled} [Nm]
118	Nyquist et. al.	M	54	182	68	3,5	LM*	395	434,5	520	455	291,1
124	Nyquist et. al.	M	64	177	82	4,2	LM*	287	315,7	490	450	244,5
126	Nyquist et. al.	M	58	174	73	4,2	LM*	224	246,4	480	455	209,9
127	Nyquist et. al.	M	56	176	79	3,7	LM*	237	260,7	465	455	244,2
129	Nyquist et. al.	M	57	178	99	3,7	LM*	349	383,9	500	455	289,3
132	Nyquist et. al.	M	57	187	45	3,8	LM*	264	290,4	445	455	310,4

*: Lateral to Medial

Source: Nyquist et al. (1985)

- Consideration of six male tibia specimen tested by Nyquist et al. (1985) with known heel to tibia plateau heights
- Acquisition of Bending Moment to fracture at Midspan
- Due to attenuation of peak values by CFC 60 filtering: increase of bending moment values by 10% ($\rightarrow M_{max}$)
- Calculation of scaled Fracture Bending Moments according to the formula:

$$M_{scaled} = [(L_{ref}/L)^3] * M_{max}$$

Anthropometric Data

PMHS Data

Injury Risk Curve

Calculation of Maximum Tibia Bending Moment

Annotations

References

Injury Risk Curve




Shapiro Wilk Normality Test results in Gaussian distribution of both the Peak BM at Midspan as well as the Scaled Fracture Moment results ($P > 95\%$).

Scaled Fracture Moment results take into account the standardized tibia heights of DIN.

Therefore, the injury risk thresholds are to be derived from this risk curve.

20% risk of tibia fracture:

50% risk of tibia fracture:



*1): Test results of six specimen taken from Nyquist et al (1985)

*2): according to formula $M_{scaled} = [(L_{ref}/L)^3] * M_{max}$ under consideration of DIN standardized tibia heights

Source: Pastor C. (2009)

$$P_{0,2} = \sum_1^6 M_{Max} / 6 = 235,7 Nm$$

$$P_{0,5} = \sum_1^6 M_{Scaled} / 6 = 264,9 Nm$$

Anthropometric Data

PMHS Data

Injury Risk Curve

Calculation of Maximum Tibia Bending Moment

Annotations

References

Calculation of Maximum Tibia BM



Flex-GT Tibia Bending Moment = [...] = 0,9977 * Human Tibia Bending Moment – 12,325


assumption: $H_{TBM} = HM_{TBM}$. $FGT_{MTBM} = FGT_{TBM}$
 $FGT_{MTBM} = 0.9977 * HM_{TBM} - 12.325$ (from reguration curve)

Source: TEG-048


Flex-GT $BM_{Tibia} = 0,9977 * 264,9 - 12,325 = 252 \text{ Nm}$

Increase of Flex-GTR BM_{Tibia} values compared to Flex-GT BM_{Tibia} :
 A1: +1,83%, A2: +10,18%, A3: +17,04%, A4: +14,58%

➔ Mean increase of Flex-GTR BM_{Tibia} compared to Flex-GT BM_{Tibia} in idealised tests: 11%
 (Flex-GT and Flex-GTR readings within ACEA/BASt joint projects on Flex-GT/GTR evaluation)



← Flex-GTR
Flex-GT →



Source: TEG-051

Calculation of Maximum Tibia BM



Flex-GTR Tibia Bending Moment =
 $1,11 * (0,9977 * \text{Human Tibia Bending Moment} - 12,325)$

Flex-GTR BM_{Tibia} = 1,11 * (0,9977 * 264,9 - 12,325) = 279,7 Nm

**Maximum deviation of
 tibia value from mean
 value within inverse tests:
 7,66 %
 (measured at Tibia A3)**

**Nine inverse tests with Flex-
 GTR, three with SN01, SN02,
 SN03 each, at 40 km/h**

Test #	Tibia A1	Tibia A2	Tibia A3	Tibia A4
Inverse test 1 [SN01]	251,4	234,3	186,2	108,9
Inverse test 2 [SN01]	257,9	236,6	184,9	111,8
Inverse test 3 [SN01]	262,0	236,1	186,8	112,7
Inverse test 4 [SN02]	262,7	251,3	194,9	114,5
Inverse test 5 [SN02]	254,0	241,2	188,4	108,9
Inverse test 6 [SN02]	256,1	240,9	185,1	110,5
Inverse test 7 [SN03]	254,2	243,2	209,0	111,5
Inverse test 8 [SN03]	255,8	243,7	207,9	113,6
Inverse test 9 [SN03]	255,6	245,8	204,0	112,6
MV	256,63	241,46	194,13	111,67
CV	1,44	2,21	5,23	1,75
Max	262,70	251,30	209,00	114,50
Min	251,40	234,30	184,90	108,90
max. Dev. from MV [%]	2,36	4,08	7,66	2,54

Upper Performance Limit (UPL) = Flex-GTR BM_{Tibia} / 1,0766 = 259,8 Nm
Lower Performance Limit (LPL) = Flex-GTR BM_{Tibia} * 1,0766 = 301,1 Nm

As type approval requires pass-/fail threshold:

Proposed Threshold Value for Flex-GTR Max. Tibia Bending Moment: 302 Nm

Anthropometric Data

PMHS Data


Injury Risk Curve

Calculation of Maximum Tibia Bending Moment

Annotations

References

- This study is limited to six cases under consideration of the anthropometric data according to DIN that is in line with Kerrigan et al. (2004).
- The test results of those six cases are found to be Gaussian distributed (not Weibull).
- The study is based on a 50% risk of tibia fracture, but:
- EEVC WG 17 proposed a maximum tibia acceleration of 150 g equal to almost 20% risk for an AIS 2+ lower leg fracture.



Source: EEVC (2002)

Anthropometric Data

PMHS Data

Injury Risk Curve

Calculation of Maximum Tibia Bending Moment

Annotations

References

Deutsche Industrie Norm DIN 33402-2: Ergonomics – Human Body Dimensions – Part 2: Values. December 2005

European Enhanced Vehicle-safety Committee (EEVC) Working Group 17. 2002. “Improved test methods to evaluate pedestrian protection afforded by passenger cars.” December 1998 report with September 2002 updates.

Kerrigan J. et al. 2004. “Tolerance of the human leg and thigh in dynamic lateral-medial 3-point bending”. International Journal of Crashworthiness, 9(6): 607-623.

Konosu A. “Review of Injury Criteria and Injury Thresholds for Flex-PLI“. 5th meeting of FlexTEG (Technical Evaluation Group). Doc TEG-048, Bergisch Gladbach, Germany, 2008.

Nyquist G. et al. 1985. „Tibia Bending: Strength and Response“. SAE Conference 1985, Paper No. SAE 851728

Zander O. „Flex-GT: Repeatability and Reproducibility of Assembly Certification and Inverse Test Results“. 5th meeting of FlexTEG (Technical Evaluation Group). Doc TEG-051, Bergisch Gladbach, Germany, 2008.

Thank you!

Bundesanstalt für Straßenwesen

(Federal Highway Research Institute)